

## Splitting Positive & Negative Frequency Components for Advanced Diversity AM Reception

J.A. Crawford June 10, 1993

Want to consider looking at the Hilbert transform for doing the spiffy AM detection where upper and lower sidebands must be separated out.

$$jx := 2 \cdot \pi \cdot \sqrt{-1}$$

$$N := 21$$

$$pp := 0..N - 1$$

$$\beta := 3 \quad I0const := I0(\beta) \quad \text{Kaiser Filter Parameter}$$


$$fc := 10.5$$

$$ni_{pp} := -\frac{N-1}{2} + pp + 0.0001$$


$$W_{pp} := \frac{I0\left[\beta \cdot \sqrt{1 - \left[\frac{2 \cdot ni_{pp}}{N-1}\right]^2}\right]}{I0const}$$

$$h_{pp} := e^{jx \cdot \left(\frac{fc}{2}\right) \cdot \frac{ni_{pp}}{N}} \cdot \frac{\sin\left(\pi \cdot fc \cdot \frac{ni_{pp}}{N}\right)}{\pi \cdot \frac{ni_{pp}}{N}}$$

$$h\left|\frac{N-1}{2}\right| := fc$$




$xf_{pp} := W_{pp} \cdot h_{pp}$       Apply Kaiser window to desired response




$$mm := 0..N - 1$$

$$FT_{pp} := \sum_{mm} \left[ xf_{mm} \cdot e^{\left( \frac{jx \cdot mm \cdot pp}{N} \right)} \cdot (-1) \right]$$

$$Mag_{pp} := 10 \cdot \log \left[ (|FT_{pp}|)^2 \right]$$





Look at amplitude out for positive & negative freq components

ii := 0..200

$$xp_{ii} := e^{jx \cdot 1 \cdot \frac{ii}{N} \cdot (1)}$$

$$xn_{ii} := e^{jx \cdot 1 \cdot \frac{ii}{N} \cdot (-1)}$$

jj := 0..150

$$yp_{jj} := \frac{\sum_{pp} (xf_{pp} \cdot xp_{jj+50-pp})}{N}$$

$$yn_{jj} := \frac{\sum_{pp} (xf_{pp} \cdot xn_{jj+50-pp})}{N}$$

